

COURSE MATERIAL

II Year B. Tech I- Semester MECHANICAL ENGINEERING



MACHINE DRAWING

R18A0306



MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

DEPARTMENT OF MECHANICAL ENGINEERING

(Autonomous Institution-UGC, Govt. of India)
Secunderabad-500100, Telangana State, India.

www.mrcet.ac.in



MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

DEPARTMENT OF MECHANICAL ENGINEERING

CONTENTS

1. Vision, Mission & Quality Policy
2. Pos, PSOs & PEOs
3. Blooms Taxonomy
4. Course Syllabus
5. Lecture Notes (Unit wise)
 - a. Objectives and outcomes
 - b. Notes
 - c. Presentation Material (PPT Slides/ Videos)
 - d. Industry applications relevant to the concepts covered
 - e. Question Bank for Assignments
 - f. Tutorial Questions
6. Previous Question Papers



MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

VISION

- ❖ To establish a pedestal for the integral innovation, team spirit, originality and competence in the students, expose them to face the global challenges and become technology leaders of Indian vision of modern society.

MISSION

- ❖ To become a model institution in the fields of Engineering, Technology and Management.
- ❖ To impart holistic education to the students to render them as industry ready engineers.
- ❖ To ensure synchronization of MRCET ideologies with challenging demands of International Pioneering Organizations.

QUALITY POLICY

- ❖ To implement best practices in Teaching and Learning process for both UG and PG courses meticulously.
- ❖ To provide state of art infrastructure and expertise to impart quality education.
- ❖ To groom the students to become intellectually creative and professionally competitive.
- ❖ To channelize the activities and tune them in heights of commitment and sincerity, the requisites to claim the never - ending ladder of **SUCCESS** year after year.

For more information: www.mrcet.ac.in

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

www.mrcet.ac.in

Department of Mechanical Engineering

VISION

To become an innovative knowledge center in mechanical engineering through state-of-the-art teaching-learning and research practices, promoting creative thinking professionals.

MISSION

The Department of Mechanical Engineering is dedicated for transforming the students into highly competent Mechanical engineers to meet the needs of the industry, in a changing and challenging technical environment, by strongly focusing in the fundamentals of engineering sciences for achieving excellent results in their professional pursuits.

Quality Policy

- ✓ To pursuit global Standards of excellence in all our endeavors namely teaching, research and continuing education and to remain accountable in our core and support functions, through processes of self-evaluation and continuous improvement.
- ✓ To create a midst of excellence for imparting state of art education, industry-oriented training research in the field of technical education.

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

www.mrcet.ac.in

Department of Mechanical Engineering

PROGRAM OUTCOMES

Engineering Graduates will be able to:

- 1. Engineering knowledge:** Apply the knowledge of mathematics, science, engineering fundamentals, and an engineering specialization to the solution of complex engineering problems.
- 2. Problem analysis:** Identify, formulate, review research literature, and analyze complex engineering problems reaching substantiated conclusions using first principles of mathematics, natural sciences, and engineering sciences.
- 3. Design/development of solutions:** Design solutions for complex engineering problems and design system components or processes that meet the specified needs with appropriate consideration for the public health and safety, and the cultural, societal, and environmental considerations.
- 4. Conduct investigations of complex problems:** Use research-based knowledge and research methods including design of experiments, analysis and interpretation of data, and synthesis of the information to provide valid conclusions.
- 5. Modern tool usage:** Create, select, and apply appropriate techniques, resources, and modern engineering and IT tools including prediction and modeling to complex engineering activities with an understanding of the limitations.
- 6. The engineer and society:** Apply reasoning informed by the contextual knowledge to assess societal, health, safety, legal and cultural issues and the consequent responsibilities relevant to the professional engineering practice.
- 7. Environment and sustainability:** Understand the impact of the professional engineering solutions in societal and environmental contexts, and demonstrate the knowledge of, and need for sustainable development.
- 8. Ethics:** Apply ethical principles and commit to professional ethics and responsibilities and norms of the engineering practice.
- 9. Individual and teamwork:** Function effectively as an individual, and as a member or leader in diverse teams, and in multidisciplinary settings.
- 10. Communication:** Communicate effectively on complex engineering activities with the engineering community and with society at large, such as, being able to comprehend and write effective reports and design documentation, make effective presentations, and give and receive clear instructions.
- 11. Project management and finance:** Demonstrate knowledge and understanding of the engineering and management principles and apply these to one's own work, as a member and leader in a team, to manage projects and in multidisciplinary environments.

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

www.mrcet.ac.in

Department of Mechanical Engineering

12. **Life-long learning:** Recognize the need for and have the preparation and ability to engage in independent and life-long learning in the broadest context of technological change.

PROGRAM SPECIFIC OUTCOMES (PSOs)

- PSO1** Ability to analyze, design and develop Mechanical systems to solve the Engineering problems by integrating thermal, design and manufacturing Domains.
- PSO2** Ability to succeed in competitive examinations or to pursue higher studies or research.
- PSO3** Ability to apply the learned Mechanical Engineering knowledge for the Development of society and self.

Program Educational Objectives (PEOs)

The Program Educational Objectives of the program offered by the department are broadly listed below:

PEO1: PREPARATION

To provide sound foundation in mathematical, scientific and engineering fundamentals necessary to analyze, formulate and solve engineering problems.

PEO2: CORE COMPETANCE

To provide thorough knowledge in Mechanical Engineering subjects including theoretical knowledge and practical training for preparing physical models pertaining to Thermodynamics, Hydraulics, Heat and Mass Transfer, Dynamics of Machinery, Jet Propulsion, Automobile Engineering, Element Analysis, Production Technology, Mechatronics etc.

PEO3: INVENTION, INNOVATION AND CREATIVITY

To make the students to design, experiment, analyze, interpret in the core field with the help of other inter disciplinary concepts wherever applicable.

PEO4: CAREER DEVELOPMENT

To inculcate the habit of lifelong learning for career development through successful completion of advanced degrees, professional development courses, industrial training etc.

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

www.mrcet.ac.in

Department of Mechanical Engineering

PEO5: PROFESSIONALISM

To impart technical knowledge, ethical values for professional development of the student to solve complex problems and to work in multi-disciplinary ambience, whose solutions lead to significant societal benefits.

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

www.mrcet.ac.in

Department of Mechanical Engineering

Blooms Taxonomy

Bloom's Taxonomy is a classification of the different objectives and skills that educators set for their students (learning objectives). The terminology has been updated to include the following six levels of learning. These 6 levels can be used to structure the learning objectives, lessons, and assessments of a course.


1. **Remembering:** Retrieving, recognizing, and recalling relevant knowledge from long-term memory.
2. **Understanding:** Constructing meaning from oral, written, and graphic messages through interpreting, exemplifying, classifying, summarizing, inferring, comparing, and explaining.
3. **Applying:** Carrying out or using a procedure for executing or implementing.
4. **Analyzing:** Breaking material into constituent parts, determining how the parts relate to one another and to an overall structure or purpose through differentiating, organizing, and attributing.
5. **Evaluating:** Making judgments based on criteria and standard through checking and critiquing.
6. **Creating:** Putting elements together to form a coherent or functional whole; reorganizing elements into a new pattern or structure through generating, planning, or producing.

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

www.mrcet.ac.in

Department of Mechanical Engineering





INTRODUCTION



COURSE OBJECTIVES

Introduction	CO1: Students learn about the conventional representation of materials, machine elements, and sizes of drawing sheets.
--------------	---

COURSE OUTCOMES

Students gain the knowledge of conventional representation of materials, machine elements, and sizes of drawing sheets.

COURSE OUTLINE

INTRODUCTION

NO OF LECTURE HOURS:

LECTURE	LECTURE TOPIC	KEY ELEMENTS	LEARNING OBJECTIVES
1.	Introduction to IS conventions.	Materials, machine component	Understanding the representation of materials machine components (B2)



CONVENTIONAL REPRESENTATION









Certain draughting conventions are used to represent materials in section and machine elements in engineering drawings.

Materials:

As a variety of materials are used for machine components in engineering applications, it is preferable to have different conventions of section lining to differentiate between various materials. The recommended conventions in use are shown in Fig.

Machine Components:

When the drawing of a component in its true projection involves a lot of time, its convention may be used to represent the actual component. Figure shows typical examples of conventional representation of various machine components used in engineering drawing.

Type	Convention	Material
Metals		Steel, Cast Iron, Copper and its Alloys, Aluminum and its Alloys, etc.
		Lead, Zinc, Tin, White-metal, etc.
Glass		Glass
Packing and Insulating material		Porcelain, Stoneware, Marble, Slate, etc.
		Asbestos, Fiber, Felt, Synthetic resin products, Paper, Cork, Linoleum, Rubber, Leather, Wax, Insulating and Filling materials, etc.
Liquids		Water, Oil, Petrol, Kerosene, etc.
Wood		Wood, Plywood, etc.
Concrete		A mixture of Cement, Sand and Gravel



DIMENSIONS:

















A drawing of a component, in addition to providing complete shape description, must also furnish information regarding the size description. These are provided through the distances between the surfaces, location of holes, nature of surface finish, type of material, etc. The expression of these features on a drawing, using lines, symbols, figures and notes is called dimensioning.

General Principles:













Dimension is a numerical value expressed in appropriate units of measurement and indicated on drawings, using lines, symbols, notes, etc., so that all features are completely defined



Conventional representation of machine components (Contd.)









Title	Subject	Convention
Straight knurling		
Diamond knurling		
Square on shaft		
Holes on circular pitch		
Bearings		
External screw threads (Detail)		
Internal screw threads (Detail)		
Screw threads (Assembly)		



Title	Subject		Convention
Splined shafts			
			
Semi-elliptic leaf spring			
Semi-elliptic leaf spring with eyes			
	Subject	Convention	Diagrammatic Representation
Cylindrical compression spring			
Cylindrical tension spring			

Conventional representation of machine component



Title	Convention	
Spur gear		
Bevel gear		
Worm wheel		
Worm		

Conventional Representation of Machine Components





UNIT-1

**SCREWS FASTENERS, KEYS, COTTERS, PIN JOINTS,
RIVETED JOINTS, SHAFT COUPLINGS AND BEARINGS**



COURSE OBJECTIVES

UNIT - 1	<p>CO2: Explain the concept of how to draw Selection of Views, additional views for machine elements and parts like Screwed fasteners, Keys, Cotter and Pin joints.</p> <p>CO3: Explain the concept of how to draw Selection of Views, additional views for machine elements and parts like Riveted joints, Shaft couplings and Bearings.</p>
----------	---

COURSE OUTCOMES

Students understand the concept of how to draw machine elements such as Screwed fasteners, Keys, Cotter and Pin joints, Riveted joints, Shaft couplings and Bearings.



COURSE OUTLINE

INTRODUCTION

NO OF LECTURE HOURS:

LECTURE	LECTURE TOPIC	KEY ELEMENTS	LEARNING OBJECTIVES
1.	Screwed fasteners	Forms of Screw threads, bolts, nuts, stud bolts, tap bolts, set screws.	1. Remember the standard formulas of component (B1). 2. Understand the how to draw a components (B2). 3. Apply the design formulas for components(B3)
2.	Keys, Cotters and Pin joints	i) Saddle keys, sunk keys ii) Cotter joint with sleeve, cotter joint with socket & spigot ends, cotter joint with a gib. iii) knuckle joint	1. Remember the standard formulas of component (B1). 2. Understand the how to draw a components (B2). 3. Apply the design formulas for components(B3)
3.	Riveted joints	plates	1. Remember the standard formulas of component (B1). 2. Understand the how to draw a components (B2). 3. Apply the design formulas for components(B3)
4.	Shaft couplings:	Draw the different types of shaft couplings	1. Remember the standard formulas of component (B1). 2. Understand the how to draw a components (B2). 3. Apply the design formulas for components(B3)
5.	Bearings	Journal, pivot and collar and foot step bearings	1. Remember the standard formulas of component (B1). 2. Understand the how to draw a components (B2). 3. Apply the design

SCREW FASTENERS




INTRODUCTION:

A machine element used for holding or joining two or more parts of a machine or structure is known as a fastener. The process of joining the parts is called fastening. The fasteners are of two types: permanent and removable (temporary). Riveting and welding processes are used for fastening permanently. Screwed fasteners such as bolts, studs and nuts in combination, machine screws, set screws, etc., and keys, cotters, couplings, etc., are used for fastening components that require frequent assembly and disassembly

Screwed fasteners occupy the most prominent place among the removable fasteners. In general, screwed fasteners are used : (i) to hold parts together, (ii) to adjust parts with reference to each other and (iii) to transmit power

SCREW THREAD NOMENCLATURE:

A screw thread is obtained by cutting a continuous helical groove on a cylindrical surface (external thread). The threaded portion engages with a corresponding threaded hole (internal thread); forming a screwed fastener. Following are the terms that are associated with screw threads shown in Fig.



Major (nominal) diameter: This is the largest diameter of a screw thread, touching the crests on an external thread or the roots of an internal thread.

Minor (core) diameter: This is the smallest diameter of a screw thread, touching the roots or core of an external thread (root or core diameter) or the crests of an internal thread.

Pitch diameter: This is the diameter of an imaginary cylinder, passing through the threads at the points where the thread width is equal to the space between the threads.



Pitch: It is the distance measured parallel to the axis, between corresponding points on adjacent screw threads.

Lead: It is the distance a screw advances axially in one turn.

Flank: Flank is the straight portion of the surface, on either side of the screw thread.

7. Crest: It is the peak edge of a screw thread, that connects the adjacent flanks at the top.


8. Root: It is the bottom edge of the thread that connects the adjacent flanks at the bottom.

9. Thread angle: This is the angle included between the flanks of the thread, measured in an axial plane.

FORMS OF THREADS:

Bureau of Indian Standards (BIS) adapts ISO (International Organization for Standards) metric threads which are adapted by a number of countries apart from India.

The design profiles of external and internal threads are shown in Fig. The following are the relations between the various parameters marked in the figure:



Metric screw thread

$$P = \text{Pitch}$$

$$H = 0.86 P$$

$$D = d = \text{Major diameter}$$

$$D_2 = d_2 = d - 0.75H$$

$$D_1 = d_2 - 2(H/2 - H/4) = d - 2H_1$$

$$= d - 1.08P$$

$$d_3 = d_2 - 2(H/2 - H/6)$$

$$= d - 1.22P$$

$$H_1 = (D - D_1)/2 = 5H/8 = 0.54P$$

$$h_3 = (d - d_3)/2 = 17/24H = 0.61P$$

$$R = H/6 = 0.14P$$

Other Thread Profiles:



Apart from ISO metric screw thread profile, there are other profiles in use to meet various applications. These profiles are shown in Fig. 5.3, the characteristics and applications of which are discussed below:

Thread (sharp): This thread profile has a larger contact area, providing more frictional resistance to motion. Hence, it is used where effective positioning is required. It is also used in brass pipe work.


British Standard Whitworth (B.S.W) Thread: This thread form is adopted in Britain in inch units. The profile has rounded ends, making it less liable to damage than sharp V-thread.

Buttress Thread: This thread is a combination of V-and square threads. It exhibits the advantages of square thread, like the ability to transmit power and low frictional resistance, with the strength of the V-thread. It is used where power transmission takes place in one direction only such as screw press, quick acting carpenters vice, etc.

Square Thread: Square thread is an ideal thread form for power transmission. In this, as the thread flank is at right angle to the axis, the normal force between the threads, acts parallel to the axis, with zero radial components. This enables the nut to transmit very high pressures, as in the case of a screw jack and other similar applications.

ACME Thread: It is a modified form of square thread. It is much stronger than square thread because of the wider base and it is easy to cut. The inclined sides of the thread facilitate quick and easy engagement and disengagement as for example, the split nut with the lead screw of a lathe.

Worm Thread: Worm thread is similar to the ACME thread, but is deeper. It is used on shafts to carry power to worm wheels. transmission. In this, as the thread flank is at right angle to the axis,



THREAD SERIES:



BIS recommends two thread series: coarse series and fine series, based on the relative values of the pitches. However, it must be noted that the concept of quality is not associated with these terms. For any particular diameter, there is only one largest pitch, called the coarse pitch and the rest are designated as fine pitches.

Table gives the nominal diameter and pitch combinations for coarse and fine series of ISO metric screw threads.

Table: Diameter-pitch combination for ISO metric threads

<i>Nominal diameter</i>		<i>Pitch</i>			
<i>First choice</i>	<i>Second choice</i>	<i>Coarse</i>	<i>Fine</i>		
			<i>1</i>	<i>2</i>	<i>3</i>
2	—	0	0.25	—	—
—	2.2	0.45	0.25	—	—
2.5	—	0.45	0.35	—	—
3	—	0	0.35	—	—
—	3.5	0	0.35	—	—
4	—	0	0.5	—	—
—	4.5	0.75	0.5	—	—
5	—	0	0.5	—	—
6	—	1	0.75	0.5	—
8	—	1.25	1	0.75	—
10	—	1	1.25	1	0.75
—	—	1.75	1.5	1.25	—



36	39	4	3	2	1.5
42	45	4.2	4 1.5	3	— 2
20	18,22	5 2	2	1.5	1
		5			
24	27	3	2	1.5	1
30	33	3	2	1.5	1
48	52	5 5	4	3	2
56	60	5.5	4	3	2
64	68	6	4	3	2
72	76	6	4	3	2
80	85	6	4	3	2
90	95	6	4	3	2
100	—	6	4	3	2
105 to 300	—	—	6	4	3

THREAD DESIGNATION:

The diameter-pitch combination of an ISO metric screw thread is designated by the letter 'M' followed by the value of the nominal diameter and pitch, the two values being separated by the sign 'x'. For example, a diameter pitch combination of nominal diameter 10 mm and pitch

1.25 mm is designated as M10 x 1.25.

If there is no indication of pitch in the designation, it shall mean the coarse pitch. For example, M 10 means that the nominal diameter of the thread is 10 mm and pitch is 1.5 mm. Following are the other designations, depending on the shape of the thread profile:

SQ 40 x 10 – SQUARE thread of nominal diameter 40 mm and pitch 10 mm
 ACME 40 x 8 – ACME thread of nominal diameter 40 mm and pitch 8 mm
 WORM 40 x 10 – WORM thread of nominal diameter 40 mm and pitch 10 mm

MULTI-START THREADS:

A single-start thread consists of a single, continuous helical groove for which the lead is equal to the pitch. As the depth of the thread depends on the pitch, greater the lead desired, greater will be the



pitch and hence smaller will be the core diameter, reducing the strength of the fastener. To overcome this drawback, multi-start threads are recommended.

In multi-start threads, lead may be increased by increasing the number of starts, without increasing the pitch. For a double start thread, lead is equal to twice the pitch and for a triple start thread; lead is equal to thrice the pitch.

In double start threads, two threads are cut separately, starting at points, diametrically opposite to each other. In triple start threads, the starting points are 120° apart on the circumference of the screws.

Multi-start threads are also used wherever quick action is desired, as in fountain pens, automobile starters, arbor press spindles, hydraulic valve spindles, etc.

RIGHT HAND AND LEFT HAND THREADS

Screw threads may be right hand or left hand, depending on the direction of the helix. A right hand thread is one which advances into the nut, when turned in a clockwise direction and a left hand thread is one which advances into the nut when turned in a counter clockwise direction. An abbreviation LH is used to indicate a left hand thread. Unless otherwise stated, a thread should be considered as a right hand one. Figure illustrates both right and left hand thread.





Fig. 5.5 Right hand and left hand threads




V-THREAD & SQUARE THREAD

The simplified representation, though it saves time, is not an effective method to convey thread forms. The schematic representation, used for the purpose is shown in Fig. In practice, the schematic representation is followed for only visible threads, *i.e.*, for external threads and internal threads in section. From the Fig. it may be observed that the crest diameters, both in external and internal threads, are drawn by thick lines. Further, the crests are represented by thin lines, extending up to the major diameter and the roots by thick lines, extending up to the minor diameter, these lines being



9 Schematic representation of threaded parts—Square threads

drawn inclined with a slope equal to half the pitch



Schematic representation of threaded parts—V-threads

BOLTED JOINT

A bolt and nut in combination Fig. is a fastening device used to hold two Parts together. The body of the bolt, called shank is cylindrical in form, the head; square or hexagonal in shape, is formed by forging. Screw threads are cut on the other end of the shank. Nuts in general are square or hexagonal in shape. The nuts with internal threads engage with the corresponding size of the external threads of




the bolt. However, there are other forms of nuts used to suit specific requirements. For nuts, hexagonal shape is preferred to the square one, as it is easy to tighten even in a limited Fig. Bolted joint space. This is because, with only one-sixth of a turn, the spanner can be re-introduced in the same position. However, square nuts are used when frequent loosening and tightening is required, for example on job holding devices like vices, tool posts in machines, etc. The sharp corners on the head of bolts and nuts are removed by chamfering

Methods of Drawing Hexagonal (Bolt Head) Nut:

Drawing hexagonal bolt head or nut, to the exact dimensions is laborious and time consuming. Moreover, as standard bolts and nuts are used, it is not necessary to draw them accurately. The following approximate methods are used to save the draughting time.

(Fig.)



Empirical relations:

Major or nominal diameter of bolt = D Thickness of nut, $T = D$

Width of nut across flat surfaces, $W = 1.5D + 3 \text{ mm}$

Radius of chamfer, $R = 1.5D$




Fig. 5.12 Method of drawing views of a hexagonal nut (Method I)



PROCEDURE:

1. Draw the view from above by drawing a circle of diameter, W and describe a regular hexagon on it, by keeping any two parallel sides of the hexagon, horizontal.
2. Project the view from the front, and the view from side, and mark the height equal to D .
3. With radius R , draw the chamfer arc 2-1-3 passing through the point 1 in the front face.
4. Mark points 4 and 5, lying in-line with 2 and 3. Locate points 8,9 on the top surface, by projecting from the view from above.
5. Draw the chamfers 4–8 and 5–9.
6. Locate points 6 and 7, lying at the middle of the outer two faces.
7. Draw circular arcs passing through the points 4, 6, 2 and 3, 7, 5, after determining the radius R_1 geometrically.
8. Project the view from the side and locate points 10, 11 and 12.
9. Mark points 13 and 14, lying at the middle of the two faces (view from the side).
10. Draw circular arcs passing through the points 10, 13, 11 and 11, 14, 12, after determining the radius R_2 geometrically.

It may be noted that in the view from the front, the upper outer corners appear chamfered.

In the view from the side, where only two faces are seen, the corners appear square.

Method 2 (Fig.)

Empirical relations:

Major or nominal diameter of bolt = D Thickness of nut, $T = D$

Width of the nut across corners = $2 D$ Radius of chamfer arc, $R = 1.5 D$

Figure illustrates the stages of drawing different views of a hexagonal nut, following the above relations, which are self-explanatory.



The above method may be followed in routine drawing work, as it helps in drawing the views quickly.

Method of Drawing Square (Bolt Head) Nut


A square bolt head and nut may be drawn, showing either across flats or corners. Following relations may be adopted for the purpose:

Major or nominal diameter of bolt = D

Thickness of nut, T


Width of the nut across flats, $W = 1.5 D + 3 \text{ mm}$

Radius of chamfer arc, $R = 2 D$



Method of drawing the views of a square

Figure shows the two views of a hexagonal headed bolt and square headed bolt, with the proportions marked.



Washers:

A washer is a cylindrical piece of metal with a hole to receive the bolt. It is used to give a perfect seating for the nut and to distribute the tightening force uniformly to the parts under the joint. It also prevents the nut from damaging the metal surface under the joint. Figure shows a washer, with the proportions marked. Figure illustrates the views of a hexagonal headed bolt with a nut and a washer in position.

Other Forms of Bolts:

Square Headed Bolt with Square Neck: It is provided with a square neck, which fits into a corresponding square hole in the adjacent part, preventing the rotation of the bolt.




Fig. 5.18 Square headed bolt with square neck

T-Headed Bolt with Square Neck:

In this, a square neck provided below the head, prevents the rotation of the bolt. This type of bolt is used for fixing vices, work pieces, etc., to the machine table having T-slots Fig.

Hook Bolt:

This bolt passes through a hole in one part only, while the other part is gripped by the hook shaped bolt head. It is used where there is no space for making a bolt hole in one of the parts.

The square neck prevents the rotation of the bolt Fig






Fig. 5.19 T-headed bolt





Fig. 5.20 Hook bolt

Eye Bolt:


In order to facilitate lifting of heavy machinery, like electric generators, motors, turbines, etc., eye bolts are screwed on to their top surfaces. For fitting an eye bolt, a tapped hole is provided, above the centre of gravity of the machine Fig.



Cap Screws and Machine Screws :

Cap screws and machine screws are similar in shape, differing only in their relative sizes. Machine screws are usually smaller in size, compared to cap screws. These are used for fastening two parts, one with clearance hole and the other with tapped hole. The clearance of the unthreaded hole need not be shown on the drawing as its presence is obvious. Figure





5.24 shows different types of cap and machine screws, with proportions marked

The bolted joints, though removable in nature, are required to stay firm without becoming loose, of their own accord. However, the joints used in the moving parts of machinery, may be subjected to vibrations. This may slacken the joint, leading to serious breakdown. To eliminate the slackening tendency, different arrangements, as discussed further, are used to lock the nuts:

LOCK NUT:

This is the most commonly used locking device. In this arrangement, a second nut, known as lock nut is used in combination with a standard nut Fig. The thickness of a lock nut is usually two-thirds D , where D is the major diameter of the bolt. The lock nut is usually placed below the standard nut. To make the joint, the lock nut is first screwed tightly and then the standard nut is tightened till it touches the lock nut. Afterwards, the locknut is then screwed back on the standard nut, which is held by a spanner. The threads of the two nuts become wedged between the threads of the bolt.






Fig. 5.26




Fig. 5.27 Lock nut

LOCKING BY SPLIT PIN

A split pin is inserted through a hole in the bolt body and touching just the top surface of the nut. Then, the ends of the pin are split open to prevent it from coming out while in use Fig.




Fig. 5.30 Wile's lock nut




Fig. 5.31 Locking by set screw




Fig. 5.28 Locking by split pin




Fig. 5.29 Castle nut

WILE'S LOCK NUT

It is a hexagonal nut with a slot, cut half-way across it. After tightening the nut in the usual manner, a set screw is used from the top of the nut, compressing the two parts. For this purpose, the upper portion of the nut should have a clearance hole and the lower portion tapped Fig.

LOCKING BY SET SCREW



In this arrangement, after the nut is tightened, a set screw is fitted in the part, adjoining the nut, so that it touches one of the flat faces of the nut. The arrangement prevents the loosening tendency of the nut Fig

GROOVED NUT

It has a cylindrical grooved collar, integrally provided at the lower end of the nut. This collar fits into a corresponding recess in the adjoining part. In this arrangement, after tightening the nut, a set screw is inserted from one end of the upper part, so that the end of the set screw enters the groove, preventing the loosening tendency of the nut Fig.

LOCKING BY SCREW

In this, a cap nut with an integral washer and with a threaded hole in the cylindrical cap, is used. A corresponding tapped hole at the top end of the bolt is also required for the purpose. In this arrangement, a set screw fitted through the cap and through the bolt end, prevents the loosening tendency of the nut, when the pitches of the main nut and the set screw are different Fig. This type of arrangement is used for fitting the propeller blades on turbine



LOCKING BY PLATE

A locking plate is grooved such that it fits a hexagonal nut in any position, at intervals of 30° of rotation. It is fixed around the nut, by means of a machine screw, as shown in Fig.

LOCKING BY SPRING WASHER

In this arrangement, a spring washer of either single or double coil is placed under the nut and tightened. The spring force of the washer will be acting upwards on the nut.

FOUNDATION BOLTS:

Foundation bolts are used for fixing machines to their foundations. Foundation bolts are made by forging from mild steel or wrought iron rods. The bolt size depends upon the size of the machine and the magnitude of the forces that act on them when the machine is in operation.

For setting the bolts in position, their positions are marked and then suspended in the holes made in the ground. Afterwards, cement concrete is filled in the space around in the bolt.

EYE FOUNDATION BOLT

This is the simplest form of all foundation bolts. In this, one end of the bolt is forged into an eye and a cross piece is fixed in it. Figure shows an eye foundation bolt that is set in concrete.

BENT FOUNDATION BOLT

As the name implies, this bolt is forged in bent form and set in cement concrete. When machines are to be placed on stone beds, the bolts are set in lead. Figure shows a bent foundation bolt that is set first in lead and then in cement concrete, resulting in a firm and stable bolt.

RAG FOUNDATION BOLT

This bolt consists of a tapered body, square or rectangular in cross-section, the tapered edges being grooved. Figure shows a rag foundation bolt that is set first in lead and then in cement concrete.







Fig: Eye foundation bolt

Fig: Bent foundation bolt


LEWIS FOUNDATION BOLT

This is a removable foundation bolt. The body of the bolt is tapered in width on one side. To use this bolt, a pit is produced in cement concrete, by using a (foundation) block. Once the concrete sets-in, the bolt is placed in it so that the tapered bolt surface, bears against the tapered face of the pit. A key is then inserted, bearing against the straight surfaces of the pit and the bolt. This arrangement makes the bolt firm in the bed. However, the bolt may be removed by withdrawing the key. This type of foundation bolt is not commonly used for fixing machines.



COTTER FOUNDATION BOLT

It is used for fixing heavy machines. It has a rectangular slot at its bottom end, to receive a cotter. For putting the bolts in position, the foundation bed is first made, providing holes for inserting cotters. Figure shows a cotter foundation bolt in position. A cast iron washer (W) placed as shown, provides bearing surface for the cotter (C).



KEYS, COTTERS AND PIN JOINTS


INTRODUCTION

Keys, cotters and pin joints discussed in this chapter are some examples of removable (temporary) fasteners. Assembly and removal of these joints are easy as they are simple in shape. The standard proportions of these joints are given in the figures.



KEYS


Keys are machine elements used to prevent relative rotational movement between a shaft and the parts mounted on it, such as pulleys, gears, wheels, couplings, etc. Figure shows the parts of a keyed



joint and its assembly.

Hollow Saddle Key

A hollow saddle key has a concave shaped bottom to suit the curved surface of the shaft, on which it is used. A keyway is made in the hub of the mounting, with a tapered bottom surface. When a hollow saddle key is fitted in position, the relative rotation between the shaft and the mounting is prevented




due to the friction between the shaft and key

Flat Saddle Key

It is similar to the hollow saddle key, except that the bottom surface of it is flat. Apart from the tapered keyway in the hub of the mounting, a flat surface provided on the shaft is used to fit this key in position.



Sunk keys may be classified as:



(i) Taper keys, (ii) parallel or feather keys and (iii) woodruff keys.

Fig:Flat Saddle Key




Fig. Key with gib

Head Following are the proportions for a gib head

Width of head, $B = 1.5 T$ If D is the diameter of the shaft, then,

Width of key, $W = 0.25 D + 2 \text{ mm}$

Thickness of key, $T = 0.67 W$ (at the thicker end)

Standard taper = 1:100



Height of head, $H = 1.75 T$

Parallel or Feather Keys

A parallel or feather key is a sunk key, uniform in width and thickness as well. These keys are used when the parts (gears, clutches, etc.)





fig: Parallel sunk key

The feather key may be fitted into the keyway provided on the shaft by two or more screws Fig. or into the hub of the mounting Fig. As seen from Fig., these keys are of three types: (i) peg feather key, (ii) single headed feather key and (iii) double headed feather key



Peg Feather Key:

In this key, a projection known as peg is provided at the middle of the key. The peg fits into a hole in the hub of the sliding member (Fig. a). Once placed in a position, the key and the mounting move axially as one unit.



Single Headed Feather Key:

In this, the key is provided with a head at one end. The head is screwed to the hub of the part mounted on the shaft (Fig. b).

Double Headed Feather Key:

In this, the key is provided with heads on both ends. These heads prevent the axial movement of the key in the hub. Here too, once placed in position, the key and the mounting move as one unit (Fig. c).

Woodruff Key:

It is a sunk key, in the form of a segment of a circular disc of uniform thickness. As the bottom surface of the key is circular, the keyway in the shaft is in the form of a circular recess to the same curvature as the key.




Fig:Woodruff

Key If D is the diameter of the shaft,

Thickness of key, W	= 0.25 D
Diameter of key, d	= 3 W
Height of key, T	= 1.35 W
Depth of the keyway in the hub, T1	=
0.5 W + 0.1 mm	
Depth of keyway in shaft, T2	=
0.85 W	

Round Keys: Round keys are of circular cross-section, usually tapered (1:50) along the length. A round key fits in the hole drilled partly in the shaft and partly in the hub Fig. The mean diameter of the pin may be taken as 0.25 D, where D is shaft diameter. Round keys are generally used for light duty, where the loads are not considerable.






Fig:Round key

COTTER JOINTS:

Cotter joints are used to connect two rods, subjected to tensile or compressive forces along their axes. These joints are not suitable where the members are under rotation. The following are some of the commonly used cotter joints:

Cotter Joint with Sleeve:

This is the simplest of all cotter joints, used for fastening two circular rods. To make the joint, the rods are enlarged at their ends and slots are cut. After keeping the rods butt against each other, a sleeve with slots is placed over them. After aligning the slots properly, two cotters are driven-in through the slots, resulting in the joint Fig





Fig. Cotter joint with sleeve




Cotter Joint with Socket and Spigot Ends

This joint is also used to fasten two circular rods. In this, the rod ends are modified instead of using a sleeve. One end of the rod is formed into a socket and the other into a spigot Fig. and slots are cut. After aligning the socket and spigot ends, a cotter is driven-in through the slots, forming the joint.



Cotter Joint with a Gib

This joint is generally used to connect two rods of square or rectangular cross-section. To make the joint, one end of the rod is formed into a U-fork, into which, the end of the other rod fits in. When a cotter is driven-in, the friction between the cotter and straps of the U-fork, causes the straps to open. This is prevented by the use of a gib.



PIN JOINTS: In a pin joint, a pin is used to fasten two rods that are under the action of a tensile force; although the rods may support a compressive force if the joint is guided. Some pin joints such as universal joints use two pins and are used to transmit power from one rotating shaft to another.



Knuckle Joint: A knuckle joint is a pin joint used to fasten two circular rods. In this joint, one end of the rod is formed into an eye and the other into a fork (double eye). For making the joint, the eye end of the rod is aligned into the fork end of the other and then the pin is inserted through the holes and held in position by means of a collar and a taper pin (Fig). Once the joint is made, the rods are free to swivel about the cylindrical pin.




Fig. Knuckle joint

SHAFT COUPLINGS

INTRODUCTION

Shaft couplings are used to join or connect two shafts in such a way that when both the shafts rotate, they act as one unit and transmit power from one shaft to the other. Shafts to be connected or coupled may have collinear axes, intersecting axes or parallel axes at a small distance. Based on the requirements, the shaft couplings are classified as: (i) rigid couplings, (ii) flexible couplings, (iii) loose or dis-engaging couplings and (iv) non-aligned couplings.

Rigid Couplings

Rigid shaft couplings are used for connecting shafts having collinear axes. These are further sub-classified into muff or sleeve couplings and flanged couplings.

Sleeve or Muff Couplings

This is the simplest of all couplings. It consists of a sleeve called muff, generally made of cast iron, which is fitted over the ends of the shafts to be connected. After properly aligning the keyways in the



shafts and sleeve, a sunk key is driven-in; thus making the coupling. Instead of a single key running the entire length of the sleeve, it is desirable to use two keys, which may be inserted from the outer ends of the sleeve; thus overcoming the possible miss-alignment between the keyways. The following are the types of muff couplings:

Butt-muff Coupling

In this, the ends of the two shafts to be coupled butt against each other, with the sleeve keyed to them, as discussed above.


Half-lap Muff Coupling

In this, the ends of the shafts overlap each other for a short length. The taper provided in the overlap prevents the axial movement of the shafts. Here too, after placing the muff over the overlapping ends of the shafts, a saddle key(s) is(are) used to make the coupling.

Split-muff Coupling

In this, the muff is split into two halves and are recessed. A number of bolts and nuts are used to connect the muff halves and the recesses provided accommodate the bolt

Fig. Butt-muff coupling






Fig. Split-muff coupling

Flanged Couplings:

These are the standard forms of couplings, most extensively used. In a flanged coupling, flanges are either fitted or provided at the ends of shafts. The flanges are fastened together by means of a number of bolts and nuts. The number and size of the bolts depend upon the power to be transmitted and hence, the shaft diameter.

Flanged Coupling with Detachable Flanges

In this, two flanges are keyed, one at the end of each shaft, by means of sunk keys. For ensuring correct alignment, a cylindrical projection may be provided on one flange which fits into the corresponding recess in the other.

Solid Flanged Coupling

Couplings for marine or automotive propeller shafts demand greater strength and reliability. For these applications, flanges are forged integral with the shafts. The flanges are joined together by means of a number of headless taper bolts.




Fig. Flanged coupling








Fig. Protected flanged coupling



Oldham Coupling

It is used to connect two parallel shafts whose axes are at a small distance apart. Two flanges, each having a rectangular slot, are keyed, one on each shaft. The two flanges are positioned such that, the slot in one is at right angle to the slot in the other.



Socket and Spigot Joint:

This type of joint is used for underground pipelines of large diameters. In this, one end of a pipe is made into a socket and the other end into a spigot. After placing the spigot end into the socket, the space between them is filled-in, partly by rope (jute or coir) and the remaining by molten lead.

Because of the flexible nature of the joint, it adapts itself to small changes in level due to settlement of earth




Fig. Socket and spigot joint



RIVETTED JOINTS FOR PLATES

INTRODUCTION

Riveted joints are permanent fastenings and riveting is one of the commonly used method of producing rigid and permanent joints. Manufacture of boilers, storage tanks, etc., involve joining of steel sheets, by means of riveted joints. These joints are also used to fasten rolled steel sections in structural works, such as bridge and roof trusses.

Rivet

A rivet is a round rod of circular cross-section. It consists of two parts, viz., head and shank (Fig.(a)). Mild steel, wrought iron, copper and aluminum alloys are some of the metals commonly used for rivets. The choice of a particular metal will depend upon the place of application.

Riveting

Riveting is the process of forming a riveted joint. For this, a rivet is first placed in the hole drilled through the two parts to be joined. Then the shank end is made into a rivet head by applying pressure, when it is either in cold or hot condition.





Fig.(a) Rivet (b) Riveting



RIVET HEADS: Various forms of rivet heads used in general engineering works and boiler construction and as recommended by Bureau of Indian Standards, are shown in Fig. The standard proportions are also indicated in the figure.

Fig.Types of rivet heads



Diamond Butt Joint:

This is one kind of butt joint made either with a single or double strap. As the name implies, the rivets in this joint are arranged in a diamond shape. Figure shows a double strap diamond butt joint. The joint is generally used to connect tie bars in bridge structures and roof trusses






Fig: Double strap diamond butt joint

Lap Joints:

In a lap joint, the plates to be riveted overlap each other. The plates to be joined are first bevelled at the edges, to an angle of about 80°. Depending upon the number of rows of rivets used in the joint, lap joints are further classified as single riveted lap joint, double riveted lap joint and so on.

In multi-row riveted joints, rows may be arranged either in chain or zig-zag fashion, as shown in Figs.

Figure shows a single riveted lap joint. The size of the rivet, d is taken as, $d = 6\text{mm}$

Where 's' is the thickness of the plates to be joined in millimeters.




Fig. Single riveted lap joint






Fig. Double riveted chain lap joint




Fig. Double riveted zig-zag lap joint

Butt Joints:

In a butt joint, the plates to be joined butt against each other, with a cover plate or strap, either on one or both sides of the plates; the latter one being preferred. In this joint, the butting edges of the plates to be joined are square and the outer edges of the cover plate(s) is (are) beveled.



In a single strap butt joint, the thickness of the strap (cover plate) is given by, $t_1 = 1.125t$ If two straps are used, the thickness of each cover plate is given by, $t_2 = 0.75t$




Fig. Single riveted, single strap butt joint




Fig. Single riveted, double strap butt joint






Fig. Double riveted, double strap chain butt joint




Fig. Double riveted, double strap zig-zag butt joint



Industrial Application of screw fasteners

- **Military** – Fasteners specially designed to withstand the stress of high temperature, high wear and corrosive environments such as engines, motors, heat exchangers and process equipment. We offer a wide range of diameters, lengths and thread configurations using stainless steel, copper alloys, alloy steels, nickel alloys and exotic alloys.
- **Oilfield** – Fasteners manufactured using stainless steel, tool alloys, nickel alloys and exotic metals that will perform well in the high stress, corrosive environment found in oilfield and mining applications. Our fasteners are used in drilling rigs, tanks and pumping equipment.
- **Turbine & Power Generation** – Fasteners used in electrical equipment, turbines, motors, exhaust systems, pumping systems and storage vessels. Nickel alloys, aluminum, steel alloys and stainless steel are used for their strength, high wear and anti-corrosive properties. Copper alloys are used for their conductive properties.

APPLICATION OF COTTER JOINT



PREPARED BY : DEVANSU KHORASIYA (GIT-15012019066)



Riveted joints in Boilers:



Coupling



BEARINGS



Tutorial Questions:

1. Draw the conventional representation of following materials
(a) Porcelain (b) Fiber (c) Lead (d) Petrol (e) Copper
2. Draw the single riveted single strap Butt joint of plate thickness as 12 mm .
Draw the half-sectional front view and side view of journal bearing which can accommodate 40 mm diameter shaft.
4. Draw the three views of a hexagonal headed bold of nominal diameter 20 mm and length 80 mm with a hexagonal nut and washer.
5. Draw the conventional representation of the following materials.
(a) Cast iron (b) Lead (c) marble (d) glass (e) water (f) concrete (g) wood
Draw the sectional front view and top view of a double riveted double strap chain Butt Joint to joint two plates of thickness 10 mm
6. Draw the sectional front, top and side view of a knuckle joint to join two rods of diameter 30 mm each.
7. Draw the three views of a hexagonal headed bold of nominal diameter 20 mm and length 80 mm with a hexagonal nut and washer.
8. Draw the sectional front view of a universal coupling joining two shafts of diameter 50 mm. Show the dimensions.
9. Draw the sectional view from the front and top view of a single riveted single strap butt joint with plates of thickness 15 mm.
10. Sketch the sectional front view of rag foundation bolt of diameter 25 mm. Show the proportionate dimensions in the drawing



Question bank for Assignments

1. Answer the following:

Sketch a (i) Hexagonal nut convention, (ii) Convention of a stud bolt.

2. Sketch the conventional representation of Square headed bolt ii. Keys.

3. Sketch the conventional representation of

i) Hexagonal bolt ii) Shaft. Iii). Mention the importance of list of materials.

4. Sketch the conventional representation of i) Eye bolt ii.) Foundation bolt.

5. Answer the following:

Sketch conventional representation of the materials steel and Lead

6. Sketch the following: Whit worth thread and Buttress thread.

7. Show the conventional representation of the following materials:

i) Wood ii. Lead iii. Straight Knurling iv. Internal screw threads v Bearing on shafts.

8. Sketch the conventional representation of the various materials.

Sketch the conventional representation of the different engineering materials.

9. Draw the triple start square threads with D as 30 mm.

10. Draw sectional front view and side view of Cotter joint with socket and spigot ends taking $d=30$ mm.

11. Draw sectional front view and top view of double riveted, zig zag joint with dia of rivet as 10 mm.

12. Draw two views of locking the nut with set screw if $D= 30$ mm.

13. Draw sectional front view and side view of the Cotter Joint with a gib of 40 square.

14. Draw sectional front view and top view of double riveted, zig zag joint with dia of rivet as 10 mm.

15. Draw two views of hexagonal headed bolt and nut and square headed bolt along with nut. ($D=30$ mm).

16. Draw two views of hexagonal headed bolt and nut and square headed bolt along with nut. ($D=30$ mm).

17. Draw the sectional front view and top view of the double riveted double strap zig zag butt joint with dia of the rivet as 14 mm.

18. Draw at least four types of thread profiles taking pitch as 20 mm.

19. Draw sectional front view and side view of Cotter joint with socket and spigot ends taking $d=30$ mm.



20. Answer any Two of the following by drawing proportionate diagrams:

Single riveted, double strap butt joint for plates of 12 mm thickness with cover plate thickness of 10 mm

ii. Mu coupling to connect two shafts of 50mm diameter.

iii. Foot step bearing for a shaft of 75 mm diameter.

21. Answer any Two of the following by drawing proportionate diagrams

Triple riveted single strap zig-zag butt joint to connect two plates of 12mm thick.

Flange coupling to connect to shafts of 20 mm diameter.

22. Answer any Two of the following by drawing proportionate diagrams

Triple riveted single strap zig-zag butt joint to connect two plates of 12mm thick.

Flange coupling to connect to shafts of 20 mm diameter.

23. Answer any Two of the following:

Draw plan and sectional elevation of a chain type double - riveted lap joint. Take the diameter of rivet as 18 mm.

Sketch a Knuckle joint showing sectional front view and top view to connect two rods of 40 mm diameter.

Draw half sectional view from the front and side view of a mu coupling to connect two shafts of 30 mm diameter.

24. Answer any Two of the following:

Draw front view with top half in section and side view of a socket and spigot type of cotter joint to connect two rods of 25 mm diameter each.

Draw sectional front view and top view of double riveted, double cover butt joint, zig-zag riveting to join plates of thickness 16 mm.

Draw proportionately a hexagonal bolt with nut. Take the diameter of the bolt as 25 mm.

25. Answer any Two of the following:

26. Draw half sectional view from the front and side view of a flange coupling to connect two shafts of 25 mm diameter.

27. Draw plan and sectional elevation of double riveted lap joint, chain riveting, taking 12mm diameter rivet.

28. Draw half sectional front view and side view of a foot step bearing for 40 mm diameter.



29. Answer any Two of the following:

i. Draw plan and sectional elevation of a double – riveted lap joint (chain riveting) taking diameter of rivet as 20 mm.

ii. Sketch two views of cotter joint with a gib to connect two square rods of side 30 mm with proper dimensions.

iii. Draw half sectional front view and side view of a rigid flange coupling to connect two shafts of 30 mm diameter.

30. Draw two views of knuckle joint with properties to connect two shafts of 25 mm diameter.

31. Draw single strap butt joint of two rows zigzag to connect two plates of 5 mm thick.

32. Draw protected flange coupling to connect two shafts of 50 mm diameter.

33. Draw spigot and socket type of pipe joint to connect 30 mm diameter pipes.

34. Draw double riveted lap joint zigzag type to join 15mm plates.

35. Draw flexible flanged coupling to join two shafts of 100 mm diameter.

36. Draw a footstep bearing for a shaft of 150 mm diameter.

37. Draw a collar bearing to a shaft of 50 mm diameter.

38. Draw a sleeve and cotter joint to connect two shafts of 30 mm diameter.

39. Draw a triple riveted single strap butt joint to connect two plates of 15 mm thickness.

40. Draw a Plummer block for a shaft of 25 mm diameter.

41. Draw a double riveted double strap chain type butt joint to connect plates of 20 mm size.

42. Sketch square headed bolt with a nut and washer

43. Draw two views of knuckle joint with properties to connect two shafts of 25mm diameter.

44. Draw single strap butt joint of two rows zigzag to connect two plates of 5mm thick

45. Draw spigot and socket type of pipe joint to connect 30 m diameter pipes





UNIT-2

ASSEMBLY DRWING



COURSE OBJECTIVES

UNIT - 2	CO4: students learn about the drawings of assembled views for the part drawings of the following using conventions like Engine parts. CO5: students learn about the drawings of assembled views for the part drawings of the following using conventions like machine parts, Valves.
-----------------	---

COURSE OUTCOMES

Students acquire the knowledge on how to assembly of different parts.



UNIT – 2

ASSEMBLE DRAWING

NO OF LECTURE HOURS:

LECTURE	LECTURE TOPIC	KEY ELEMENTS	LEARNING OBJECTIVES
1.	Engine parts	stuffing box, cross head, Eccentric, Petrol Engine connectingrod	1. Understand the PART drawing of assembly components (B2). 2. Apply the assembly procedure (B3)
2.	machine parts	Screws jack, Machine Vice, Plummer block, Tailstock	1. Understand the PART drawing of assembly components (B2). 2. Apply the assembly procedure (B3)
3.	Valves	spring loaded safety valve, feed check valve	1. Understand the PART drawing of assembly components (B2). 2. Apply the assembly procedure (B3)



ENGINE PARTS

1) STUFFING BOX:




Fig. Stuffing box



Parts list:

Part No.	Name	Matl	Qty
1	Body	CI	1
2	Gland	Brass	1
3	Bush	Brass	1
4	Stud	MS	2
5	Nut, M12	MS	2



STEAM ENGINE CROSSHEAD:

Crosshead is used in horizontal steam engines for connecting the piston rod and connecting rod.




Fig. 18.2 Steam engine crosshead

Figure 18.2 shows the part drawings of a steam engine crosshead. The crosshead, with the help of slide block 4, reciprocates between two guides provided in the engine frame. The gudgeon pin 3, connects the slide blocks with the crosshead block 1. This acts as a pin joint for the connecting rod (not shown in figure). The piston rod 2 is secured to the crosshead block by means of the cotter 5. The assembly ensures reciprocating motion along a straight line for the piston rod and reciprocating cum oscillatory motion for the connecting rod.



CROSSHEAD:

Figure shows the details of another type of steam engine crosshead. It consists of a body or slide block 1, which slides in-between parallel guides in the frame of the engine. The piston rod end 2 is fitted to the crosshead with the help of bolts 5 and nuts 6 and 7 after placing the brasses 4, and cover plate 3 in position.





Fig.Crosshead



ECCENTRIC:


It is used to provide a short reciprocating motion, actuated by the rotation of a shaft. Eccentrics are used for operating steam valves, small pump plungers, shaking screens, etc. The components of an eccentric are shown in isometric views Fig. for easy understanding of their shapes. Rotary motion can be converted into a reciprocating motion with an eccentric, but the reverse conversion is not possible due to excessive friction between the sheave and the strap. The crank arrangement, in a slider crank mechanism however, allows conversion in either direction.




Details of an Eccentric

CONNECTING ROD

PETROL ENGINE CONNECTING ROD



Assembly of connecting rod:



Parts list


Part No.	Name	Matl.	Qty.
1	Rod	FS	1
2	Cap	FS	1
3	Bearing brass	GM	2
4	Bearing bush	P Bronze	1
5	Bolt	MCS	2
6	Nut	MCS	2

Fig. Petrol engine connecting rod



OTHER MACHINE PARTS:

SCREW JACK: Screw jacks are used for raising heavy loads through very small heights. Figure shows the details of one type of screw jack. In this, the screw 3 works in the nut 2 which is press fitted into the main body 1. The Tommy bar 7 is inserted into a hole through the enlarged head of the screw and when this is turned, the screw will move up or down, thereby raising or lowering the load



* Screw jack



MACHINE VICE:

The details of a plain machine vice are shown in Fig. It consists of the base 1 which is clamped to the machine table using two T-bolts. The sliding block 3 is fixed in the centre slot of the base by means of the guide screw 4. The movable jaw 2 is fixed to the sliding block with four screws 8 and 7. One of the serrated plates 5 is fixed to the jaw of the base by means of screws 6 and the other to the movable jaw by the screws 7. One end of the guide screw is fixed to the base by means of the washer 9 and nut 10 (not shown in figure). The movable jaw is operated by means of a handle (not shown) which fits onto the square end of the guide screw






Fig. Machine vice

PLUMMER BLOCK:



LATHE TAIL-STOCK:






Parts list

Part No.	Name	Matl.	Qty
1	Body	CI	1
2	Barrel	MS	1
3	Spindle with washer & nut	MS	1
4	Centre	CS	1
5	Spindle bearing	CI	1
6	Hand wheel	CI	1
7	Clamping lever	MS	1
8	Stud	MS	1
9	Feather key	MS	1
10	Screw	MS	4



VALVES:

STEAM STOP VALVE:




Sl. No.	Name	Matl.	Qty.
1	Valve body	CI	1
2	Bonnet	Brass	1
3	Gland tightening nut	MS	1
4	Gland	Brass	1
5	Sleeve	MS	1
6	Collar	MS	1
7	Stuffing box packing	Aspes	1
8	Stem with screw	MS	1
9	Actuating screw end	MS	1
10	Screwed sleeve	Brass	1
11	Valve seat	GM	1
12	Screw	MS	1
13	Hand wheel	CI	1
14	Nut	MS	1

Steam stop valve




Fig. spring loaded safety valve



Part No.	Name	Matl	Qty	Part No.	Name	Matl	Qty
1	Body	CI	1	8	Toggle-pin	MS	1
2	Valve seat	GM	1	9	Lever guide	MS	1
3	Valve	GM	1	10	Lever	FS	1
4	Cover	CI	1	11	Fulcrum pin	MS	1
5	Cover bush	Brass	1	12	Weight	CI	1
6	Spindle	MS	1	13	Lever pin	MS	1
7	Toggle	MS	1	14	Stud with nut M20	—	6


Fig. spring loaded safety valve





AIR COCK:

This valve is used to control air or gas supply. The details of an air cock are shown in Fig. It consists of a plug 2 which is inserted into the body 1, from the bottom. The rectangular sectioned spring 4 is placed in position at the bottom of the plug and seated over the screw cap 3. The screw cap is operated to adjust the spring tension. Lever 5 with square hole is used to operate the cock. By a mere 90° turn, the cock is either opened or closed fully.



INDUSTRIAL APPLICATIONS:

1 Marine Gas-Tight Bulkhead Stuffing Box between Pump and Engine Room.



2. Steam Engine Cross Head used in Marine/Locomotive engines.



Eccentric



Pistons used in Automobile



SCREW JACK is used for lifting the load.




Machine Vice:



Plumber block




Lathe tail stock used in industries for different operations



Feed Check valve

FEEED CHECK VALVE



Feed check valve works as NRV (Non-return valve).

Prevents the back flow of water from the boiler when the feed water pump is either not working or in case of its failure.



Steam stop valve



Code No: R15A0310

R15

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

II B.Tech II Semester supplementary Examinations, April/May 2019

Machine Drawing

(ME)

Roll No									
---------	--	--	--	--	--	--	--	--	--

Time: 3 hours

Max. Marks: 75

Note: This question paper contains two parts A and B

Part A consists of three Questions, answer any two questions. Each question carries 15 marks.

Part B consists of one question which is compulsory. Which carries 45 marks.

Part-A (30Marks)

Answer any two of the following (2x15=30M)

3. Draw the conventional representation of following materials
(a) Porcelain (b) Fiber (c) Lead (d) Petrol (e) Copper
4. Draw the single riveted single strap Butt joint of plate thickness as 12 mm .
5. Draw the half-sectional front view and side view of journal bearing which can accommodate 40 mm diameter shaft.

Part-B (45Marks) (1x45=45M)

6. Assemble the parts of spring loaded safety valve as shown in the figure and draw
 - a) Sectional front view
 - b) Top view

P.T.O



R17

Code No: R17A0310

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

II B. Tech I Semester Regular Examinations, November 2018

Machine Drawing

(ME)

Roll No										
----------------	--	--	--	--	--	--	--	--	--	--

Time: 3 hours

Max. Marks: 70

Note: This question paper Consists of 2 parts. Answer any two questions from Part-A, which carries of 28 Marks and Part-B consists of one question which is compulsory which carries 42 marks.

Part- A (28 Marks)

Answer any two of the following (14*2=28)

5. Draw the three views of a hexagonal headed bolt of nominal diameter 20 mm and length 80 mm with a hexagonal nut and washer.
6. Draw the conventional representation of the following materials.
(a) Cast iron (b) Lead (c) marble (d) glass (e) water (f) concrete (g) wood
7. Draw the sectional front view and top view of a double riveted double strap chain Butt Joint to joint two plates of thickness 10 mm.

Part-B (42 Marks)

(1*42=42M)

8. Develop the assembly drawing views as mentioned below of an Eccentric using the part drawings shown in Figure.1.
(iii) Half-Sectional Front View with top half in section



(iv) Side view from right




Figure.1 Details of Eccentric



R15

Code No: R15A0310

MALLA REDDY COLLEGE OF ENGINEERING & TECHNOLOGY

(Autonomous Institution – UGC, Govt. of India)

II B.Tech II Semester supplementary Examinations, Nov/Dec 2018

Machine Drawing

(ME)

Roll No									
---------	--	--	--	--	--	--	--	--	--

Time: 3 hours

Max. Marks: 75

Note: This question paper contains two parts A and B

Part A consists of Three questions among them Two questions should be answered Which carries 30 marks.

Part B Consists of one question, which is compulsory, which carries 45 Marks.


Part-A (30Marks)


Answer any two of the following (2x15=30M)

7. Draw the following material conventions
(i) CI (ii) Water (iii) Wood (iv) concrete (v) Leather
8. Draw front view and top view of double riveted zig-zag lap joint of 10mm plate thickness.
9. Draw the sectional front, top and side view of a knuckle joint to join two rods of diameter 30 mm each.

Part-B(45Marks) (1X45=45M)

10. Assemble all the parts of the stuffing box for a vertical steam engine, show the following figure and draw
 - a) Half sectional view from the front, with left half in section
 - b) View from above. All dimensions are in mm





Parts list

Part No.	Name	Matl	Qty
1	Body	CI	1
2	Gland	Brass	1
3	Bush	Brass	1
4	Stud	MS	2
5	Nut, M12	MS	2

